


BACK VIEW OF MAIN GENERATOR



FRONT VIEW OF MAIN GENERATOR

GENERATOR MAGNET LOCATIONS

Figure 4.

(Numbers shown are frequency numbers)




FIGURE 5 - MAIN GENERATOR COVER

MODELS A, B, BC, BV, C, CV, D, DV, E, AND RT
 MODEL B-2 SERIAL NUMBERS BELOW 40304
 MODEL C-2 SERIAL NUMBERS BELOW 40460
 MODEL RP-2 SERIAL NUMBERS BELOW 2151




FIGURE 6 - MAIN GENERATOR COVER

MODEL B-2 SERIAL NUMBER 40304 AND ABOVE
 MODEL C-2 SERIAL NUMBER 40460 AND ABOVE
 MODEL RP-2 SERIAL NUMBER 2151 AND ABOVE